

Model	OS	Music		USB charging
		Bluetooth	USB	
iPhone8	iOS 16.7.8	○	○	○
iPhoneX	iOS 15.5	○	○	○
iPhoneXR	iOS 15.5	○	○	○
iPhone11	iOS 15.5	○	○	○
iPhone11 Pro	iOS 15.5	○	○	○
iPhoneSE(2nd)	iOS 15.5	○	○	○
iPhone12	iOS 15.5	○	○	○
iPhone12 Pro	iOS 15.5	○	○	○
iPhone12 ProMax	iOS 15.5	○	○	○
iPhone12 Mini	iOS 15.5	○	○	○
iPhone13	iOS 15.5	○	○	○
iPhone13 Pro	iOS 15.5	○	○	○
iPhone13 ProMax	iOS 15.5	○	○	○
iPhone13 Mini	iOS 15.5	○	○	○
iPhoneSE(3nd)	iOS 16.0	○	○	○
iPhone14	iOS 16.3	○	○	○
iPhone14 Pro	iOS 16.3	○	○	○
iPhone14 ProMax	iOS 16.3	○	○	○
iPhone15	iOS 17.4	○	○	○
iPhone15 Pro	iOS 17.4	○	○	○
iPhone15 ProMax	iOS 17.4	○	○	○
iPhone16	iOS 18.3.1	○	○	○

- ※ The results of this check are for the mobile phone used for verification.
The results are not guaranteed for all mobile phone models of the same model number.
- ※ The mobile phone models listed have been tested under certain conditions by February 17, 2025.
Depending on the type of mobile phone, specifications may be changed after operation is confirmed, and the information in the list may be changed.
Please note that communication and some functions may not work.
- ※ The results of this confirmation are especially related to the operation of the interface for the mobile phone of Navi, and do not evaluate or guarantee the call quality, data communication ability, etc.
- ※ Please note that as of [As of February 17, 2025], mobile phone types that have not been surveyed or whose operation has not been confirmed are not listed.
- ※ In the table, mobile phone models marked with "○＊" may not function properly depending on the mobile phone settings.
- ※ In the table, mobile phone models marked with "△" some functions cannot be used.
- ※ In the table, mobile phone models with the "x" function cannot be used.
- ※ In the table, mobile phone models marked with "-" do not support the corresponding functions.