

Oceania "SUZUKI Memory Navigation" connectable iPod List (As of February 2026). English only

Model	OS	Music		USB charging
		Bluetooth	USB	
Apple iPhone 8	iOS 16.7.8	○	○	○
Apple iPhone X	iOS 15.5	○	○	○
Apple iPhone XR	iOS 15.5	○	○	○
Apple iPhone 11	iOS 15.5	○	○	○
Apple iPhone 11 Pro	iOS 15.5	○	○	○
Apple iPhone 12	iOS 15.5	○	○	○
Apple iPhone 12 Pro	iOS 15.5	○	○	○
Apple iPhone 12 Pro Max	iOS 15.5	○	○	○
Apple iPhone 12 Mini	iOS 15.5	○	○	○
Apple iPhone SE (2nd generation)	iOS 15.5	○	○	○
Apple iPhone SE (3rd generation)	iOS 16.0	○	○	○
Apple iPhone 13	iOS 15.5	○	○	○
Apple iPhone 13 Pro	iOS 15.5	○	○	○
Apple iPhone 13 Pro Max	iOS 15.5	○	○	○
Apple iPhone 13 Mini	iOS 15.5	○	○	○
Apple iPhone 14	iOS 16.3	○	○	○
Apple iPhone 14 Pro	iOS 16.3	○	○	○
Apple iPhone 14 Pro Max	iOS 16.3	○	○	○
Apple iPhone 15	iOS 17.4	○	○	○
Apple iPhone 15 Pro	iOS 17.4	○	○	○
Apple iPhone 15 Pro Max	iOS 17.4	○	○	○
Apple iPhone 16	iOS 18.3.1	○	○	○
Apple iPhone 16e	iOS 26.0.1	○	○	○
Apple iPhone 17	iOS 26.2	○	○	○
Apple iPhone 17 Pro	iOS 26.2	○	○	○
Apple iPhone 17 Pro Max	iOS 26.2	○	○	○

※ The results of this check are for the mobile phone used for verification.

The results are not guaranteed for all mobile phone models of the same model number.

※ The mobile phone models listed have been tested under certain conditions by February 2026.

Depending on the type of mobile phone, specifications may be changed after operation is confirmed, and the information in the list may be changed.

Please note that communication and some functions may not work.

※ The results of this confirmation are especially related to the operation of the interface for the mobile phone of Navi, and do not evaluate or guarantee the call quality, data communication ability, etc.

※ Please note that as of February 2026, mobile phone types that have not been surveyed or whose operation has not been confirmed are not listed.

※ In the table, mobile phone models marked with "○\*" may not function properly depending on the mobile phone settings.

※ In the table, mobile phone models marked with "△" some functions cannot be used.

※ In the table, mobile phone models with the "x" function cannot be used.

※ In the table, mobile phone models marked with "-" do not support the corresponding functions.